


⚠ WARNING

Fusible fittings contain an eutectic alloy plug. The eutectic alloy plug has a specific melting point (see table on other side). If the fitting is exposed to temperatures at or above this melting point, the eutectic alloy plug will melt and the pressure inside the fitting will be released to atmosphere.



Stamp	Color Code	Melting Point, °F (°C)
160	Black	160 (71)
212	Orange	212 (100)
255	Green	255 (124)
281	Red	281 (138)

Swagelok — Swagelok Company
© 2007 Swagelok Company
Printed in U.S.A., CP
December 2007, R0
MS-CRD-0107