

Installation

- 1. Install the universal mount in its delivered, fully assembled condition with the **strainer cap** facing *down*.
- When attaching a steam trap to the universal mount, follow the steam trap manufacturer's recommendations for proper bolt torque.

Swaqelol

www.swagelok.com

Replacing the Strainer Element and Gasket

- Δ
 - Before servicing any installed <u>universal</u> <u>mount</u>, you must depressurize the system.
- 1. Unthread the strainer cap and remove.
- 2. Remove the strainer gasket and discard.
- 3. Remove the **strainer element** and clear any debris from element, or replace with a new element.
- Apply a system-compatible lubricant to all surfaces of a new strainer gasket.
- Install the strainer element, the new strainer gasket, and the strainer cap in the order shown.
- 6. Tighten the **strainer cap** to the body with 500 in.·lb (60 N·m, 575 cm·kg) of torque.

Swagelok – TM Swagelok Company © 2003 Swagelok Company Printed in U.S.A. 7-03, CP MS-INS-UM, R0